

Einbauanleitung



EN Installation manual
FR Instructions de montage
NL Montagehandleiding
IT Guida per il montaggio
ES Instrucciones de montaje
PT Instruções de instalação
PL Instrukcja montażu
CZ Montážní návod
SK Návod na montáž
SI Navodila za vgradnjo
RU Руководство по монтажу
GR Οδηγίες τοποθέτησης
EE Paigaldusjuhend
LV Uztādīšanas instrukcija
LT Montavimo instrukcija
RO Manual de montare
HU Beépítési útmutató
HR Upute za ugradnju
BG Монтажна инструкция

EDL, EDG, EDS Rx

EDL




D





C

B
mind. 4x
max. 12x




B1
mind. 4x
max. 12x



A

EDL XX., Rx 200



A

EDL XX., Rx 100

EMR, ESR Rx 200

E




1


EDG



D




C




B

mind. 4x
max. 12x




B1

mind. 4x
max. 12x



A

EDG XX., Rx 200



A

EDG XX., Rx 100




EMR, ESR Rx 200

E






1



EDS







1	6	6
---	---	---

Rx











2 B





R8 / R6 H/K 200




2 C




R7 / R4 H/K 200













Rx xx. H/K **200**






Rx xx. H/K **100**













The roof window.



www.roto-contacts.com



www.roto-extra.com

Roto Frank DST Vertriebs-GmbH
Wilhelm-Frank-Straße 38-40
97980 Bad Mergentheim
Deutschland

